



Table of contents

1. Introduction	1
1.1 Application	1
1.2 Features	1
1.3 Structure	2
1.4 Measuring principle: Time-of-flight method	3
1.5 Technical data	4
2. Installation	7
2.1 Installation considerations	7
2.2 Mounting	9
3. Wiring	11
3.1 Wiring diagram	11
3.2 Terminal blocks	12
3.3 Cable	12
4. Operation	13
4.1 display and keys	13
4.2 Two working mode	13
5. Calibration	21
6. Trouble-shooting	22