



KARI Float Switch Operation *Manual*



Start

Large amount of liquid.
Discharging pump starts.



Stop

Lower limit for discharging.
Discharging pump stops.



Image 2H shows the operation
of the KARI Float Switch