

## QUICK INSTALLATION GUIDE




## KFA2

4-wire TDR-Sensor with single rod, wire rope or coaxial probe for continuous level measurement and point level detection in liquids and light solids, with analog and switching output.

### DOCUMENT DESCRIPTION

This quick installation guide gives instructions for mounting, wiring, and basic configuration of KFA2. This will be sufficient to achieve a fully functional sensor in most applications. **For further details and advanced configuration of KFA2, please contact your local distributor or KFA directly.**

### INSTALLATION PROCEDURE



### CONTACT

KFA AG  
WEGGISGASSE 40  
P.O. BOX 5224  
6000 LUZERN 5  
SWITZERLAND

**PHONE** +49 [15 77] 7 82 17 29

**E-MAIL** STENGELE@KFA.AG

**WEB** WWW.KFA.AG