Introduction — Use of this Manual — 3

Part I: Digital Electronic modules
Local Operation (Front Panel)

Local Use / Interface GUI — 5
Front Panel — 7
GUI Menu for Local operation — 9

Preparation of a Remote Client File Set — 17

GUI MENU Locking Front Panel — 19
IP Port Locking Front Panel — 19

Part II: Digital Electronic modules
Remote Operation via IP/Ethernet

IMPORTANT — 20
Remote Operation via IP/Ethernet — 21
Port Number — 21
Protocol — 21
Client Software — 21
Client Software Installation — 22
Connection — 23
Client Software — 24
Connection — 25
Client Software — 26
Connection — 27
Client Software — 28
Connection — 29
Client Software — 30
Connection — 31
Client Software —