

Product Information MAN-63

FOOD

Pressure Gauge MAN-63



Application

· Hygienic pressure measurement

Application examples

· Local display without power supply

Hygienic design/Process connection

- · Hygienic process connection with CLEANadapt
- · Conforming to 3-A Sanitary Standard for versions with DIRECTadapt
- · All wetted materials are FDA-conform
- · Gauges completely made of stainless steel
- · Complete overview of process connections: see order code
- The Anderson-Negele CLEANadapt system offers a flow-optimized, hygienic and easily sterilizable installation solution for sensors.

Features

- · CIP-/ SIP-cleaning up to 149 °C (300 °F)/ maximum 60 minutes
- IP 66, housing for optimized cleanability
- · Complete device is certified by 3-A-SSI
- · With CLEANadapt an easy adaption to all process connection is possible
- · Zero adjustable
- · Surface R₃ ≤ 0.6 µm (0.6 microns, 24 micro-inches) is standard

Options

- · Case filling with glycerine for damping
- · Actuating fill with Neobee M20

Authorizations





MAN-63 / TC3/4



MAN-63 / S



Hygienic elastomer free sealing principle for MAN-63 / S

