

Table of contents

1. SCOPE	1
1.1. Scope of application.....	1
1.2. Affected components.....	2
1.3. Exclusions.....	2
2. DEVICE DESCRIPTION	2
2.1. Affected series.....	2
2.2. Operating conditions.....	2
2.3. Safety features.....	2
2.4. Safety-related components and parts.....	2
3. INSTALLATION NOTES	3
3.1. Technical conditions.....	3
3.2. Settings.....	3
3.2.1. Stop Position.....	3
3.2.2. Safety conditions.....	4
3.3. Testing.....	4
3.3.1. Functional test.....	4
3.3.2. Functional safety proof test.....	4
4. APPLICATION NOTES	4
4.1. Electrical installation.....	4
4.2. Test instructions.....	4
4.3. Rescue instructions.....	4
5. DECLARATION OF CONFORMITY	5

1. Scope

The Safety manual will refer only to devices Ch 8000 with the special requirements for safety technology in accordance with the EN ISO 13849 system version (EN 13849-2).

1.1. Device identification

The identification of the device is directly attributable to the manufacturer of the device series Ch 8000 in which the device name is indicated by a 4-digit code for identifying device options. Devices with the option 8L 2 are marked with "1" at position 4 and "2" at position 5 of the code.

UWT Level Control		Ch 8000-8L 2 Revision 1
SN:		
Ch 8000-8L 2		
Model:		
Code:	<input type="checkbox"/> 8L 1 <input type="checkbox"/> 8L 2 <input type="checkbox"/> 8L 3 <input type="checkbox"/> 8L 4 <input type="checkbox"/> 8L 5	
Accessories:		
Serial:	
	See instruction manual for proper operation	

Equal markings correspond with specific to device identification